INSTALLATION MANUAL

Split Duct Ceiling Air Conditioner

Cardiff®
Air Conditioning

Thank you very much for purchasing our air conditioner,
Before using your air conditioner , please read this manual carefully and keep it for future reference.

2020001A1702

14. TRIAL RUN

Please conduct in accordance with “Trial Run Tenor Nameplate” on the electric control box.

CAUTION

1. Perform the trial run only after the outdoor unit has been powered on for over 12 hours.
2. Check that all valves are opened before trial run.
3. Check the electric safety before trial run.
4. Do not perform compulsory operation in any way.(It is very dangerous if the protection device is not active)

14.1. Perform trial run only after all installations are finished.
14.2. Confirm the following issues before trial operation, and ✓ the box for the confirmed items.

Check whether the indoor unit and the outdoor are installed properly. ☐

Check whether the piping and wiring are correct. ☐

Check whether the refrigerant pipeline system is inspected for leakage. ☐

Check whether the drain is smooth. ☐

Check whether the heat insulation is perfect. ☐

Check whether the ground cables are connected correctly. ☐

Check whether the pipe length and the refrigerant amount are recorded. ☐

Check whether the supply voltage is equal to the rated voltage of the air conditioner. ☐

Check whether any obstacles exist at the air inlet/outlet of the indoor or outdoor unit. ☐

Open the gas valve and the liquid valve. ☐

Connect the power supply to preheat the air conditioner. ☐

14.3. Install the remote controller holder as required by the user. The holder must be installed in a location suitable for transmitting the signals of the remote controller to the indoor unit.

14.4. Trial run
Use the remote controller or wire controller (matched) to let the air conditioner run in the cooling mode. Inspect the following items against the operation manual. (If any fault occurs, remove the fault by reference to the Section headed “Faults of Air Conditioner and Causes” in the Operation Manual.)

Indoor unit

(1) Check whether the switch of the remote controller or wire controller is normal.
(2) Check whether the functional keys of the remote controller or wire controller are normal.
(3) Check whether the indoor temperature conditioning is normal.
(4) Check whether the indicators illuminate normally.
(5) Check whether the manual operation buttons are normal.
(6) Check whether the drain function is normal.
(7) Check whether the connective copper pipes and the drain pipes generate condensate due to loose wrapping.
(8) Open the air inlet grille to check whether any penetration or leak of water occurs, especially at the drain stopper.
(9) Check whether any vibration or abnormal sound occurs during the operation.
(10) Test whether the unit works normally in the heating mode.

Outdoor unit

(1) Check whether any vibration or abnormal sound occurs during the operation.
(2) Check whether the air, noise and condensate generated by the unit affect the neighbors.
(3) Check whether any refrigerant is leaked.

NOTE :

When you start the air conditioner immediately after connecting the power supply, or restarting the air conditioner after shutting it down, the air conditioner is protected, and the compressor will be started 3 minutes later.

14.5 Refrigerant leak precautions
This air conditioner uses refrigerant R22. The R22 is safe refrigerant which is harmless and non-flammable.
The room for placing the air conditioner should have a proper space. Even if refrigerant leakage occurs, the density threshold will not be crossed. Additional measures may also be taken.

[Density threshold: Density of the Freon gas not harmful to human body. Density threshold of R22: 0.3 [kg/m^3]]

Check the density threshold in the following sequence, and take the corresponding measures.
1. Calculate the quantity of refrigerant to be replenished (A [kg])
Total refrigerant quantity = refrigerant replenishment quantity upon shipment (12[kg]) + additional refrigerant replenishment corresponding to the pipe length
2. Calculate out the indoor volume (B[m^3]) (according to the minimum volume)
3. Calculate out the refrigerant density

$$\frac{A\ [kg]}{B\ [m^3]} \le \text{Density threshold: } 0.3\ [kg/m^3]$$



Figure 35

Measures against crossing of the refrigerant density threshold
1. In order to decrease the refrigerant density and keep it within the density threshold, please install a mechanic ventilation device. (keep ventilating)
2. In case frequent ventilation is impossible, please install the leakage detection alarm device linked with the mechanical ventilation device.



(The leakage detection alarm device should be installed at the place vulnerable to retention of the refrigerant)

Figure 36

CONTENTS PAGE

1. PRECAUTIONS....1
2. INSTALLING SITE....1
3. ACCESSORY(INDOOR UNIT)....1
4. INSTALLING THE INDOOR UNIT....2
5. INSTALLING THE OUTDOOR UNIT....3
6. INSTALL THE CONNECTIVE PIPE....6
7. AIRTIGHT TEST....6
8. PIPING THERMAL INSULATION....6
9. EXPELLING AIR....7
10. INSTALL THE DRAIN PIPE....8
11. ELECTRIC CONNECTION....8
12. METHODS OF CONFIGURING AND SELECTING INSTALLATION....10
13. CONSTRUCTION AND VENTILATION PIPELINE DESIGN SCHEME....11
14. TRIAL RUN....12

1.PRECAUTIONS

- Read this user manual carefully before installing the equipment.
- The air conditioner must be installed by professional technicians.
- When installing the indoor unit and its accessory pipes, adhere to this user’s manual as far as possible.
- Inspect and make sure the piping and cabling are correct before pair conditioner.
- This information may change with the update of this machine, and no further notice will be given for such change.

CAUTION

After installing the air conditioner properly, the installer shall demonstrate how to use and maintain the air conditioner correctly to the user, and then prompt the user to read the operation manual and installation manual properly.

WARNING

Practice shows that most problems of using the duct air conditioner are caused by improper installation. Improper installation cannot ensure normal operation of the air conditioning unit, and it is costly to correct Φsuch problems. Therefore, attach importance to installation.

2. INSTALLING SITE

INDOOR UNIT

- Install the unit where enough space of installation and maintenance is available.
- Install the unit where the ceiling is horizontal and enough for bearing the weight of the indoor unit.
- Install the unit where the air inlet and outlet are not baffled and are the least affected by external air.
- Install the unit where the supply air flow can be sent to all parts in the room.
- Install the unit where it is easy to lead out the connective pipe and the drain pipe.
- Install the unit where no heat is emitted from a heat source directly.

OUTDOOR UNIT

Install the unit where {enough space of installation and maintenance is available.
- Install the unit where the air inlet and air outlet are free from obstacles and strong wind.
- Install the unit in a dry and well ventilated place.
- Install the unit where the bearing surface is level and can bear weight of the unit, and is suitable for installing the unit horizontally without increasing noise or vibration.
- Install the unit where the operation noise and the expelling of air do not affect neighbours.
- Install the unit where no flammable gas is leaked.
- Install the unit where it is convenient for pipe connection and electric connection.

CAUTION

Installing the equipment in any of the following places may lead to faults of the equipment (if that is inevitable, consult the supplier):

A. The site contains mineral oils such as sulfide gas.
B. Factories where the supply voltage fluctuates seriously.
C. Inside a car or cabin.
D. Place like kitchen where oil permeates.
E. Place where strong electromagnetic waves exist.
F. Place where flammable gases or materials exist.
G. Place where acid or alkali gases evaporate.
H. Other special environments.

Precautions before installation:
Decide the correct way of conveying the equipment.
Try to transport this equipment with the original package.
If the air conditioner needs to be installed on a metal part of the building, electric insulation must be performed, and the installation must meet the relevant technical standards of electric devices.

3. ACCESSORY(INDOOR UNIT)

Note: If in the wire control mode, the accessories do not include display panel assembly remote controller or mounting bracket.

Accessory name	Quantity	Shape	Purpose
Midea Commercial Air Conditioner User Service Guide	1	———	(must be delivered to the customer)
OWNER’S MANUAL	1	———	———
Installation Manual	1	This user manual	———
Throttling assembly	2	———	Connection system
Drip pipe	1	———	Connect to the drain pipe
Display panel subassembly	1	———	Receive remote controller signal
Sheath of refrigerant lead-in/lead-out pipes	4		
Remote controller	1		
7# battery	2		

Precautions of operating the remote controller:

- Do not throw or slam the remote controller.
- Operate the remote controller within the receiving scope of the indoor unit, and direct the transmitting part of the remote controller to the receiver of the indoor unit.
- The remote controller should be over 1m away from the television or sound box.
- Do not place the remote controller at a moist place, near the heat sources such as stove, or expose it directly in the sunlight.
- Ensure correct positive and negative poles when loading the batteries.

4. INSTALLING THE INDOOR UNIT

4.1 Installation space

Ensure enough space required for installation and maintenance.



Figure 1



Figure 2

4.2 Install Φ10 pendant bolts or ground bolts



Figure 3

1. Use Φ10 or bigger screws. The screw material is high-quality carbon steel (whose surface is zinc plated or undergoes other rustproof treatment) or stainless steel.
2. The treatment of the ceiling varies between buildings. For detailed measures, consult with the fitting-out staff.
3. Fix the pendant bolts firmly and reliably in light of the specific situation.
4. Installation of the pendant bolt in different environments.

Wooden structure

Put rectanglar sticks across the beams, and set pendant bolts.



Figure 4

New concrete roughcast

Set it with embedded bushes or embedded bolts.



Figure 5

13. CONSTRUCTION AND VENTILATION PIPELINE DESIGN SCHEME

■ Examples of construction and ventilation pipeline design scheme (Flowering hidden series)



■ Construction and ventilation pipeline design scheme



12. METHODS OF CONFIGURING AND SELECTING INSTALLATION

	Material name	Characteristics, advantages and other contents
1	Air inlet wooden grille  Filter	1. Install the filter at the main body grille in case the storey height is low, and at the main body of the indoor unit in case the storey height is high. 2. It cleans conveniently at the time of installing/uninstalling the filter. 3. The button structure is easy to install and uninstall.
2	Hose (for absorbing noise) 	1. For purpose of air inlet. 2. Must adopt fire-resistant materials. (Those materials other than specified by Midea shall not be applied) 3. The heat insulation material must be glass wool.
3	Hose (for general purpose)	1. For purpose of air outlet. 2. Must adopt fire-resistant materials. (Those materials other than specified by Midea shall not be applied) 3. The heat insulation material must be glass wool.
4	Air inlet noise pipe	1. Install the unit at the air inlet so that the air flows smoothly and the noise is lower. 2. The noise value varies with the length. 3. The hose joint should be bent lest detachment of the pipe.
5	Air outlet noise pipe	1. Install the unit at the air outlet so that the air flows smoothly and the noise is lower. 2. The noise value varies with the length. 3. The hose joint should be bent lest detachment of the pipe.
6	Distributor 	1. Install the unit at a diffuser so that the air flows smoothly and the noise is lower. 2. Select 1BY2 or 1BY3 according to the quantity of the diffusers. 3. The diffuser pipes should preferably have the same length after branching, and the minimum length of the ventilation pipes is 5m.
7	Rectangular Air outlet 	1. Fixed model that diffuses air at a 360°angle. 2. The outline size should increase when the air volume is over 350CMH. (for above 303), i.e., when about 9 diffusers are required, the outline size should increase. 3. The diffuser pipes should preferably have the same length after branching, and the minimum length of the ventilation pipes is 5m.

	Material name	Characteristics, advantages and other contents
8	Air outlet	1. Fixed model that diffuses air at a 360°angle. 2. The outline size should increase when the air volume is over 350CMH. (for above 303), i.e., When about 9 diffusers are required, the outline size should increase. 3. Proper air speed: For air speed of over 2-3.5m/s, select other diffusers (with greater noise). 4. Install the diffuser pipe if it is necessary to install the model of over 3.5m/s. 5. For purpose of cooling-only model
9	Air outlet	1 The lengthwise adjustable model which diffuses air at a 360°angle. 2. With the change of the cooling/heating air flow, the horizontal and vertical distance of the fan can be adjusted (applicable to department store and exhibition hall where the decorative effect is essential).
10	Air outlet ←Rectangular Round→	1. Low noise compared with other air outlets. Applicable to tall buildings that require along distance of air conditioning. 2. Select the ventilation pipe connection calibre according to the distance and the airspeed. 3. Applicable to storey height of over 5m (for design of tall storeys such as temple, consult Midea).
11	Linear diffuser 	1. The fan is the adjustable type which can change direction of air flow. It is used for deluxe decoration. 2. The outline size should increase when the air volume is over 450CMH. (3 or 4SOLT) When about 6 diffusers are required, the outline size should increase. 3. If the proper air speed is 2.5 5m/s and actual air speed reaches over 5m/s, it is necessary to choose other diffusers (with higher noise values).
12	Air outlet wooden grille 	1. Low noise compared with other air outlets. Applicable to tall buildings that require along distance of air conditioning. 2. Select the ventilation pipe connection calibre according to the distance and the airspeed. 3. Applicable to storey height of over 5m (for design of tall storeys such as temple, consult Midea).
Auxiliary materials	Duct wrapping tape	1. Flanges and pipelines connected to the ventilation pipes. 2. When the noise pipe is connected with the hose, the ventilation pipe tape must be applied (otherwise, with only adhesive tape, the adhesion will be weakened due to change of temperature).
	Aluminium adhesive tape 	1. It is used to prevent glass wool leak and seal the gas at the time of connecting the flanges and pipelines of the ventilation pipes. 2. Entwine for over 3 circles. 3. Use ventilation pipe-specific tapes (instead of ordinary adhesive tapes). In order to ensure the installation quality and durability, it is necessary to use auxiliary materials of standard specifications provided by Midea Electronics and the auxiliary products of the specified manufacturers.

Old concrete roughcast

Use embedded bolts, embedded pulling plugs, and embedded stick harness



(Pipe pendant embedded bolt)

Figure 6

Steel beam and girder structure

Set and use supportive angle steel.



Figure 7

4.3 Suspending the indoor unit

Use a hoisting device to hoist the indoor unit, align it with the installation screw, adjust the horizontality and then tighten it.



Figure 8

4.4 Design and connection of duct

1. The duct design must comply with the national heating air conditioner pipeline design specifications.
2. The accessories and materials must be produced by professional manufacturers.
3. In order to prevent air flow shorting, do not keep the air inlet pipe near the air outlet pipe.
4. Install a filter at an easy-to-maintain place such as intake pipe. (Otherwise, the duct will gather on the air heat exchanger and lead to
fault and water leak of the air conditioner.)
5. In order to suppress noise effectively, install noise suppression and sound insulation devices, especially in the noise-sensitive spaces
such as meeting rooms.
6. For connection of the flange plane, use non-flammable canvas adapter to prevent transmission of vibration. For its size, see the indoor
unit outline diagram. Use M6X20 screws (configured on site) for connection.
7. All pipelines must be connected closely and soundly without leak of air. The pipelines must be adiabatic and free from condensation.

Key points of duct connection



Figure 9

NOTE :

Prepare the assemblies other than air conditioner gas on the site.



Air outlet duct connection screw hole location diagram

Figure 10



Return air duct rivet screw hole location diagram

Figure 11

5. INSTALLING THE OUTDOOR UNIT

5.1 Construction checkpoints

5.1.1. Installation
- Check the model and name to avoid mistaken installation.

5.1.2. Refrigerant pipe
- The refrigerant pipes must have the specified diameter.
- Nitrogen of a certain pressure must be filled into the refrigerant pipe before welding.
- The refrigerant pipe must undergo heat insulation treatment.
- After the refrigerant pipe is installed completely, the indoor unit cannot be powered on before performing the airtight test and creating a vacuum.

5.1.3. Airtight test
- The refrigerant pipe must undergo the airtight test [with 2.94MPa ($30kgf/cm^2G$) nitrogen].

5.1.4. Creating a vacuum
- Be sure to use the vacuum pump to create a vacuum of the connective pipe at both air side and liquid side concurrently.

5.1.5. Refrigerant replenishment
- If the pipe is longer than the reference pipe, the refrigerant replenishment quantity for each outdoor unit should be calculated through the formula obtained according to the actual length of the pipe.

- Record the refrigerant replenishment quantity, actual length of pipe and the height difference of the indoor & outdoor units onto the operation confirmation table (on the electric control box) of the outdoor unit in advance for future reference.

5.1.6. Electric wiring

Select the power supply capacity and wire size according to the design manual. The power wire size of the air conditioner should be greater than that of ordinary motors.

- In order to prevent misoperation of the air conditioner, do not interleave or entwine the power cable (380V 3N~ 50Hz) with the connection wires (low-voltage wires) of the indoor/outdoor unit.
- Power on the indoor unit after performing the airtight test and making a vacuum.

5.1.7. Trial run

Perform the trial run only after the outdoor unit has been powered on for over 12 hours.

5.2. Installation space

1. When installing the unit, leave a space for maintenance shown in the following figure. Install the power supply at the side of the outdoor unit. For installation procedure, see the relevant installation manual.
2. Ensure enough space for installation and maintenance.(see the following figure)



Installation & maintenance surface

Figure 12



Top view of the outdoor unit (multiple units installed)

Figure 13

NOTE :

1. In case any obstacles exist above the outdoor unit, such obstacles must be 2000mm above the outdoor unit.
2. If miscellaneous articles are piled around the outdoor unit, such articles must be 400mm below the top of the outdoor unit.

5.3. Conveying outdoor unit

5.3.1. Use 4 steel ropes of a Φ 6mm or bigger size to hoist the outdoor unit and convey it into the room.

5.3.2. In order to prevent scratch and deformity the outdoor unit, apply a guard board to the surface of contact between the steel wire and the air conditioner.

5.3.3. Remove the cushion for use in the transport after finishing the transport.



Figure 14

- The distance of the foundation bolt is shown in the following figure.



Figure 15

- Snow protection facilities must be installed in the snowfall areas. (See the figure) (in case the snow protection facilities are incomplete, faults may occur). In order to prevent influence caused by snow, set up raised pavilion, and install snow protection sheds at the air inlet and11.0 air outlet.



Figure 16

5.4. Refrigerant pipe

5.4.1. The refrigerant pipe adapter is located inside the outdoor unit. So remove the left front board first.(four M6 screws; one M4 screw)

5.4.2. The pipe can be connected from the front left lower side or the bottom notch of the outdoor unit.

5.4.3. When the pipe is connected from the front side, the pipe can be led out through the pipe & wire panel.

5.4.4. In case the pipe is connected from the bottom notch, install it leftward, rightward or backward after leading it out.

5.4.5. When the pipe is led from the front, use a cover plate to seal the bottom notch in order to prevent intrusion of dust or trash.



Figure 17



Figure 18

NOTE :

When welding the refrigerant pipe, in order to prevent internal oxidation of the pipe, nitrogen must be filled in. Otherwise, the oxidized chips may block refrigerating circulatory system.

11.4 Electric wiring diagram



NOTE :

1. Pay attention to the phase sequence of the power supply. If the phase sequence is reversed, the compressor will not start. Meanwhile, the fault indicator of the outdoor electric control board will light up. For details, see Outdoor unit wring diagram on the cover plate of the electric control box.
2. After shifting the phase sequence, power on the unit until the fault indicator goes out and the compressor starts up normally.

9.5 Procedure of using stop valve

- Open the spool until it touches the stop block. Do not attempt to open further.
- Use a spanner or a similar tool to tighten the bonnet.
- The bonnet tightening torque is shown in aboveTable “Tightening torque”.

Upon completion of installation, open all valves before trial run. Each unit has two valves of different sizes located at the outdoor unit side. Of the two valves, one is gas valve and the other is liquid valve. The procedure of opening/closing the valve is shown in the right figure (Figure 29).

1) Procedure of opening the valve: Open the square-head cover, use a spanner to capture the square head and open it thoroughly. Then tighten the square-head cover.
2) Procedure of closing the valve: Same as the procedure of opening the valve, but rotate the spanner clockwise thoroughly.

9.6 Refrigerant charged volume

1. Refer to the nameplate of the unit for refrigerant volume, provided that one way length of the pipe is no more than 5m.
2. Please refre to the following table for refrigerant volume, provided that one way length of the pipe is longer than 5m.

R22 additional refrigerant volume caculated method (Unit: kg):

Liquid side piping diemeter	Additional refrigerant volume is equivalent to the length of piping
Φ16	0.19 kg/m×（L-5）

NOTE :

1. As per to the pipe circuit length for additional refrigerant,If the pipe length is exceed to the sstandard length.
2. Please take note of the refrigerant charged volume perpare for your future maintain and repair.

L---------Liquid side length (m)

10. INSTALL THE DRAIN PIPE

10.1 Install the drain pipe of the indoor unit
In order to prevent drain overflow, install a drainage controller at place 1 of the drain pipe. (The drainage controller is designed to smoothen the drainage when the static pressure outside the unit is high, especially at the air inlet, in addition to remove stink through the drain pipe.)
The drain of water is natural. In the construction, the external pipe of the outdoor unit slants downward at a gradient of 1/50~1/100. The number of bends and folds of the drain pipe should not exceed 2. Try to avoid bends in order to prevent trash accumulation. In the construction, do not drop trash into the drip tray or drain pipe of the indoor unit.
Upon completion of installing the drain pipe, remove the inspection panel. Put water into the drip tray to check whether the water can be drained levelly and steadily.



Figure 30

NOTE :

Drain pipe trash gains easily at the drainage controller. Be sure to install a stopper and a structure that cleans up trash easily.

10.2 Trial draining of the drain pipe
Open the side panel of the indoor unit, fill water inward, and check whether the water can be drained smoothly. Check water leak at the joint.

10.3 Heat insulation of drain pipe
10.3.1. After making sure that the water drains smoothly and no water is leaked, use adiabatic wool bushes to preserve heat of the drain pipe. Otherwise, condensate will occur.
10.3.2. Ensure the thermal insulation material is coated on the water drain pipe which part through inside of house.
10.3.3. Make sure the water drainage pipe be termal insulated.

11. ELECTRIC CONNECTION

11.1 Electric wiring

CAUTION

1. Use special power supply for the air conditioner. Design power supplies specific to the indoor unit and outdoor unit. The supply voltage must comply with the nominal voltage.
2. The external supply circuit of the air conditioner must have a ground wire, and the power supply ground wire of the indoor unit must be connected with the external ground wire firmly.
3. The wiring must be performed by professional technicians according to the circuit diagram.
4. Distribute the wires according to the relevant electric technical standards promulgated by the State, and set the Residual Current -operated Circuit Breaker (RCCB) properly.
5. The power wire and the signal wire shall be laid out neatly and properly, without mutual interference or contacting the connection pipe or valve.
6. No power cable is attached to this equipment. The user can select the power cable by reference to the stipulated power supply specifications. No joint of wires is allowed.
7. Upon completion of wire connection, double check it and then connect the power supply.

11.2 Specifications of power supply

	INDOOR UNIT	OUTDOOR UNIT
Model	BSAH-150HR	UCV-150HT
Power	220-240V 50Hz	380-415V 3N~50Hz
Switch capacity of the main power supply/ fuse(A)	40/20	60/50
Indoor unit power cable (mm^2) Includes grounded wire	RVV-300/500 3×2.5 mm^2	
Outdoor unit power cable (mm^2) Includes grounded wire		YCW-450/750 5×9 mm^2
Connective wire between indoor unit and outdoor unit (mm^2)		RVV-300/500 4×1 mm^2
Wire controls connective wire (mm^2)	RVVP-300/300 5×0.5 mm^2 (Shielded wire)	

11.3 Power wires
The power wires are as follows: (schematic diagram)



Figure 31

5.4. Refrigerant pipe



Figure 19

6. INSTALL THE CONNECTIVE PIPE

Check the height difference between the indoor unit and the outdoor unit, and check the length and number of bends of the refrigerant pipeline, which must meet the following requirements:
Max. height difference.....20m
(If the height difference is greater than 5m, it is best to put the outdoor unit above the indoor unit)
Max. pipeline length.....50m
Max. number of bends.....15

- In the process of installing the connective pipe, do not let the air, dust or foreign substance intrude into the pipeline system.
- Install the connective pipe only after fixing the indoor and outdoor units.
- Keep dry when installing the connective pipe. Do not let moist intrude into the pipeline system.

Procedure of connecting pipes

1. Measure the required length of the connective pipe, and make the connective pipes in the following procedure.
1) Connect the indoor unit first, and then connect the outdoor unit. The pipe bend should be handled carefully, without damaging the pipe.

NOTE :

Before screwing up the flared nut, apply refrigerant oil at the outer surface of the pipeline flare and the taper surface of the connection nut. Screw up the nut for 3~4 circles beforehand (see Figure 20).
When connecting or disconnecting the pipeline, be sure to use two spanners concurrently.
Do not rest the weight of the connective pipe on the adapter of the indoor unit. Too heavy load on the adapter of the indoor unit may deform the pipe and thus affect the cooling/heating effect.

2) The valve of the outdoor unit should be closed completely (as in the factory status). Every time when connecting the pipe, screw off the nut at the valve, and connect the flared pipe (within 5 minutes). If the nut is put away for a long time after being screwed off the valve, dust and other foreign substance may intrude into the pipeline system and lead to fault. Before connecting the pipe, use the refrigerant (R-407C) to expel air out of the pipe.
3) After the refrigerant pipe is connected to the indoor and outdoor units, expel air as instructed in the “Expel air” section. After expelling the air, screw up the nut at the maintenance orifice.

A. Precautions for the flexible part of the pipeline
- The bend angle shall not exceed 90°.
- The bend shall be preferably in the middle of the pipe length, and higher bend radiuses are preferred.
- Do not bend the flexible pipe for over 3 times.

B. Bend the thin-wall connective pipe
- When bending the pipe, cut out a notch of the desired size at the bend of the adiabatic pipe, and then expose the pipe (wrap the pipe with the wrapping tape after bending it).
- The radio of the elbow pipe should be as large as possible to prevent flattening or crush.
- Use the pipe bender to make close elbow pipe.

7. AIRTIGHT TEST

Charge pressure nitrogen or R22 gaseous refrigerant for airtight test after finish the connection procedure between indoor unit and outdoor unit

NOTE :

1. Airtight test empoly aerocrete pressure[2.9MPa(30kg/cm²G)].
2. Screw up the spools of high valve and low valve before gas pressurization.
3. Pressure the gas from the ventilated orifice of low pressure valve.
4. During the gas pressurization, please keep the high pressure valve and low pressure valve in closed status.
5. Application of Oxygen, flammable gas or toxic gas for airtight test are forbidden.
6. Please employ soapy water or leakagemeter for air leakage detection of all junctions.

8. PIPING THERMAL INSULATION

Prevent malfunctions from condensation by refrigerant piping and water drain tubes, please be sufficiently perform the condensate prevention of thermal insulation operation.

NOTE :

1. Applicate normal thermal insolution materials, as well as additional thermal insulation cotton, which thickness at least 10 mm (16~20 kg/m^2), for refrigerant piping and water drain tube thermal insulation, provided that the ceiling temperature condition would be in high (temperature) and high humidity (Dew point temperature not less than 23 °C), (e.g, Inside the ceiliing which constructed by moorstone, or the outdoor temperature is the same as the one inside of the ceiling)
2. Please use heat resistant material for themal insulate material on gas side piping.
3. Coat thermal insulation materials on liquid side and gas side separately, more over, the gas side piping inside of the indoor unit must be kept thermal insulation soundly, do not drip water outside of the unit casing.
4. Please seal piping by ethylene resin band for prevent water leakage after add axiliary thermal insualtion material into piping.

8.1 Use purchased copper pipe

When the cooper pipe is purchased from the market, be sure to use the heat insulation materials of the same type (with a thickness of over 9mm).



Figure 20

Figure 21



Figure 23

8.2 Deploy the pipelines

8.2.1.1.Drill a porthole on the wall, and put the hole sheath and hole cover through the wall.
8.2.1.2. Place the connective pipe together with the indoor & outdoor connection wires. Use wrapping tape to tie them tight. Do not let air penetrate into it lest condensation and drips of moist.
8.2.1.3. Pull the connective wrapped connective pipe from outdoor through the sheath which gets through the wall, and lead it into the room.Lay out the pipelines carefully lest damage to the pipes.
8.2.2. Make a vacuum of connective pipeline.
8.2.3. After the above steps are completed, the spool of the valve of the outdoor unit should be completely open, and the refrigerant pipeline of the indoor unit and the outdoor unit should be smooth.
8.2.4. Use a leak detector or soap water detect leak carefully to prevent leakage.
8.2.5. Put on an adiabatic envelope (accessory) at connective pipe adapter of the indoor unit, and wrap it tight with the wrapping tape lest condensate and leakage.

8.3 Flare

a. Use a pipe cutter to cut off the pipe.



Figure 23

b.Pull the pipe into the rear flare of the connective nut.



Figure 24

8.4 Tighten the nut

Align with the connective pipe

- Screw up the connection pipe nut manually, and use a spanner to tighten it as shown in Figure 25.



Figure 25

NOTE :

According to the installation conditions, too large torque will damage the flaring, and too small torque will lead to looseness and leakage. Determine the tightening torque by reference to the following table.

To external dime.	Tighten torque N.m	Additional tighten torque N.m
Φ9.53	24.5(2.5 kgf.m)	29.4(3.0 kgf.m)
Φ12.7	49.0(5.0 kgf.m)	53.9(5.5 kgf.m)
Φ15.9	78.4(8.0 kgf.m)	98.0(10.0 kgf.m)
Φ19.0	98.0(10.0 kgf.m)	117.7(12.0 kgf.m)

9. EXPELLING AIR

9.1.From the following table, select a method of expelling air.

Length of connective pipe (single pass)	Procedure of expelling air
Less than 5m	Use refrigerant in the outdoor unit
5~15m	Use vacuum pump or refrigerant tank.

9.2. Use the refrigerant in the outdoor unit to expel air (see Figure 26 and Figure 27)
1. Screw up the pipe nuts at A, B, C and D completely.
2. Loosen and remove the square-head cover of valves A and B, rotate the square-head spool of valve B counterclockwise for 45 degrees and stay for about 10 seconds, and then close the spool of valve B tightly.
3. Detect leak for all adapters at A, B, C and D. After making sure that no leak exists, open the maintenance orifice nut of valve A. After all air is expelled, tighten the maintenance orifice nut of valve A.
4. Open the spools of valves A and B completely.
5. Tighten the square-head cover of valves A and B completely.



Figure 26



Figure 27

9.3 Use refrigerant tank to expel air (see Figure 26 and Figure 27)
1. Screw up the pipe nuts at A, B, C and D completely.
2. Loosen and remove the square-head cover and the maintenance orifice nut of valves A and B.
3. Connect the filler hose of the refrigerant tank with the maintenance orifice of valve A.
4. Lon the valve of the refrigerant tank, continue filling refrigerant for 6 seconds to expel the air, and tighten the nut of valve B quickly.
5. Loosen the valve of the refrigerant tank again, and fill the refrigerant for 6 seconds. Detect leak for all adapters at A, B, C and D. After making sure that no leak exists, screw off the filler hose. After all the filled refrigerant is expelled, screw up the maintenance orifice nut of valve A quickly.
6. Open the square-head spools of valves A and B completely.
7. Tighten the square-head cover of valves A and B.

9.4 Use a vacuum pump to expel the air (Figure 28):
(For method of using the manifold valve, see the operation manual of manifold valve)
1. Loosen and remove the maintenance orifice nut of valve A, and connect the filler hose of the manifold valve to the maintenance orifice of valve A (tighte n both valve A and valve B).
2. Connect the filler hose adapter to the vacuum pump.
3. Open the low pressure (Lo) handle of the manifold valve completely.
4. Start the vacuum pump to extract air. At the beginning of extracting air, slightly loosen the maintenance orifice nut of valve B, check whether any air enters it (the vacuum pump noise changes, and the multimeter indicates from negative to 0). Then tighten this maintenance orifice nut.
5. Upon completion of vacuuming, tighten the low pressure (Lo) handle of the manifold valve completely and stop the vacuum pump. Keep extracting air for over 15 minutes. Check whether the multimeter points at -1.0X10^5Pa(-76cmHg).
6. Loosen and remove the square-head cover of valves A and B. After opening valves A and B completely, tighten the square-head cover of valves A and B.
7. Remove the filler hose off the maintenance orifice of valve A, and then tighten the nut.



Figure 28